




CLOVER MINI & FLEX


QUICK REFERENCE GUIDE

HOW TO CONNECT TO WI-FI


1.) Navigate to the home screen on your device and click the **'Settings'** App




2.) Select **Network & Internet**




3.) Toggle on Wi-Fi & long press **'Wi-Fi'** to see a list of networks



4.) Click the secure network you want to connect to



5.) Enter the network password



6.) Click **Connect**

